Pine Carrier

1

2

3

4



Parts List

Step	Qty	Description
1	1	Axle 10
1	1	Bushing - 1/2
2	1	Large wheel
2	1	Large tire
2	1	Bushing
2	1	Bushing - 1/2
3	2	Liftarm 1x15
3	4	Half Pin
4	2	Brace - 5x3 triangle
4	2	Half Pin
5	4	Axle 3 - stud
5	4	Bushing - 1/2
6	4	Small wheel
6	4	Small tire
7	2	Liftarm 1x9
7	2	Bushing
8	2	Crank with pin
8	2	Axle 4
9	2	Gear - 20 tooth double bevel
9	2	Gear - 12 tooth double bevel
10	2	Gear - 24 tooth
10	2	Crank with pin
11	2	Long Pin - axle hole
11	2	Long Pin
11	2	Long Pin
12	12	EARLY Wood



5

6





7



8

12



11



10



9